

Perdüre EJF

application instructions

LINEAR FEET PER GALLON							
WIDTH DEPTH	1/8"	1/4"	3/8"	1/2"	5/8"	3/4"	1"
1/4"	616.0	308.0	205.3	154.0	123.2	102.7	77.0
1/2"	308.0	154.0	102.70	77.0	61.6	51.3	38.5
3/4"	205.3	102.7	68.4	51.3	41.1	34.2	25.7
1"	154.0	77.0	51.3	38.5	30.8	25.7	19.3
1 1/4"	123.2	61.6	41.1	30.8	24.6	20.5	15.4
1 1/2"	102.7	51.3	34.2	25.7	20.5	17.1	12.8
1 3/4"	88.0	44.0	29.3	22.0	17.6	14.7	11.0
2"	77.0	38.5	25.7	19.3	15.4	12.8	9.6
2 1/2"	61.6	30.8	20.5	14.7	12.3	10.3	7.7
2 3/4"	51.3	25.7	17.6	12.8	10.3	8.6	6.4

